

INSTRUCTION

Toledo Flat
901451.002



RZB
LIGHTING



~ 220 - 240 V 50/60 Hz IP 40 IK06



2 x 1,5 mm²



1,50 mm²



[mm]



[mm]



LED



1 x 4,2 W

D 148, H 2

DA 128, HE
27-53, S 1-20



[lm]

470



[W]

5



A+



A+



222 g

CCT [K]

3000

CRI

80

RG

RG 0



7 A / 260 μs



[St.]

40



[St.]

64




[St.]

40



[St.]

64



INSTRUCTION
WARTUNGSPLAN/
MAINTENANCE
SCHEDULE


DIN EN 61340-5-1




EN 12464
EN 13201



EN 12464
EN 13201











EN 12464



2020-03-02


www.rzb.de

1





9





Bei Fragen zu unseren Symbolen, besuchen sie folgende Webseite:

If you have any questions about our signs, visit the following website:

www.rzb.de/fileadmin/assets/downloads/PDF/RZB_Symbolklaerung.pdf



INSTRUCTION


901451.002



	982072.002	D 150, H 55	510 g
	982319.002	D 153, H 60	80 g







RZB - Rudolf Zimmermann, Bamberg GmbH

Rheinstraße 16
96052 Bamberg

Telefon: 0951/7909-0
Telefax: 0951/7909-198

E-mail: info@rzb-leuchten.de