



OKO GET-U-HOME COMPRESSOR & SEALANT USER'S MANUAL



For all tubeless tyres
Repairs punctures up to 7mm in diameter

CONTROL LAYOUT



- A.** Compressor ON/OFF button
- B.** LCD Display
- C.** Light switch
- D.** Air Hose
- E.** – Button (decrease pressure value)
- F.** + Button (increase pressure value)
- G.** M Button (change PSI/BAR units)
- H.** Adaptors for balls, inflatables
- I.** 12V Power Plug
- J.** Multi-Function LED Light
- K.** OKO 'Get-U-Home' tyre sealant

INSTRUCTIONS



1. Try to position tyre valve at 4 o'clock or 8 o'clock.
2. Pull up the sealant cap and take off the valve core remover (VCR). Unscrew the tyre valve core, using the VCR. Keep the core safe: do not lose it.
3. If possible, remove the object embedded in the tyre.
4. Using the filling tube, squeeze sealant into the tyre. Use the whole bottle for a car, motorbike, trailer or caravan tyre. (Half for a bike, mobility or barrow tyre).
5. Using the VCR, screw the valve core back in place.
6. Attach the compressor Air Hose to the valve, clip in place. Attach the 12V Power Plug to the car power socket. Select the required PSI or BAR pressure and turn on the compressor.
7. The inflation will take roughly 5 minutes: compressor will normally stop when it reaches the desired pressure. Disconnect the compressor.
8. Drive vehicle immediately to force sealant into the puncture – if safe to do so, stop after 200 metres or 4 rotations of the wheel. If the tyre has gone flat, reinflate and drive again. If that fails, you must call for assistance. Use the flashing light on the compressor to warn other vehicles.

TECHNICAL SPECIFICATION

Voltage	DC12V
Max Current	<10A
* Inflate Time	5 Minutes
Max Pressure	100PSI
Cable Length	2950±100mm
Hose Length	470±50mm
Operation Temperature	-10~60°C
Dimensions	185*77*176mm
Net Weight	0.98KGS
Continuous Working Time	No more than 30 minutes
Tyre Sealant	250ml

* Based on a flat standard tyre 195/65R15 to 35PSI

WARNINGS



- Do not drive at speeds over 50mph/80km/h after fixing your puncture.
- This repair kit will not cure tyre sidewall punctures, faulty tyre valves or damaged wheel rims.
- For safety reasons, use this kit only to drive home or to the nearest tyre garage: have the tyre checked and repaired or replaced by professionals as soon as possible.